

EWI4000s

プリセット音色リスト

01 Singing Saw	26 TrainToHastings	51 Deep Bass	76 Pitchy
02 J-Judd	27 BuffyCramdon	52 Detune Pulse	77 Detune Saw
03 Sumo	28 Saw -4	53 DuckSauce	78 DirtyDown4th
04 Wood Wind	29 Square Wave 90%	54 Warm Detune	79 DarkBass
05 Mimi	30 Fat Saw	55 Dual PWM	80 Warm Detune
06 Pulse Brass	31 Ambient Brass	56 Bright Synth	81 Colorful-Melody 1
07 Double Reed	32 Judd4000	57 M EWI	82 Colorful-Melody 2
08 SoulSaw-4	33 Gross Saw	58 Wood Wind 2	83 Colorful-Melody 3
09 Mellow	34 Dual Pulse	59 DownNDirty	84 Colorful-Melody 4
10 Nightcrawler	35 Soprano	60 Earthy	85 Colorful-Star
11 HowLowCanYouGo	36 Funky Cry Baby	61 Edgy Pulse	86 Colorful-Shine
12 Fat Bottom	37 NYStreets-3rd	62 Square Wave Wah	87 SP1 Cantabile Saw
13 Funky Wah	38 Square Wave 75%	63 Reed	88 SP2 Truth EWI 1
14 Bright Wah	39 FatterSaw	64 Feedbacker	89 Miyazaki 1
15 Recorder	40 Saw+5	65 Fat PWM	90 Miyazaki 2
16 Mix Lead	41 Clear Saw	66 Smooth Synth	91 Miyazaki 3
17 SpiritVoice_5th	42 Synth Solo	67 Wide PWM	92 Miyazaki 4
18 Tuba	43 Cantabile Saw	68 Saxy	93 Miyazaki 5
19 Solid Brass	44 Stonehenge	69 Oxygen	94 Retro Wind Synth
20 Squids+5	45 Crispy	70 Common Fanfare	95 Simple Pulse
21 Pipe	46 Square Wave 10%	71 ClareInNet	96 Retro EWI Brass
22 Tonette	47 Soft Pulse	72 YawnHummer+5	97 T-Island
23 OctaveSteps	48 Silky	73 Mass Ave.	98 Pan Flute Pulse
24 SteamPipe	49 Espresso	74 Dual Pulse	99 Talking Saw
25 Square Wave 50%	50 WoodNGlue	75 New wood	100 Dualphonic-5th