

EWI4000sw Preset List

1	Singing Saw	26	TrainToHasthings	51	Deep Bass	76	Pitchy
2	J-Judd	27	BuffyCramdon	52	Detune Pluse	77	Detune Saw
3	Sumo	28	Saw -4	53	DuckSauce	78	DirtyDown4th
4	Wood Wind	29	Square Wave 90%	54	Warm Detune	79	DarkBass
5	Mimi	30	Fat Saw	55	Dual PWM	80	Warm Detune
6	Pluse Brass	31	Pluse Brass	56	Bright Synth	81	Singing Saw
7	Double Reed	32	Judd4000	57	M EWI	82	J-Judd
8	SoulSaw-4	33	Gross Saw	58	Wood Wind 2	83	Sumo
9	Mellow	34	Dual Pulse	59	DownNDirty	84	Wood Wind
10	Nightcrawler	35	Soprano	60	Earthy	85	Mimi
11	HowLowCanYouGo	36	Funky Cry Baby	61	Edgy Pulse	86	Pluse Brass
12	Fat Bottom	37	NYStreets-3rd	62	Square Wave Wah	87	Double Reed
13	Funky Wah	38	Square Wave 75%	63	Reed	88	Coloful-Melody 1
14	Bright Wah	39	FatterSaw	64	Feedbacker	89	Coloful-Melody 2
15	Recorder	40	Saw+5	65	Fat PWM	90	Coloful-Melody 3
16	Mix Lead	41	Clear Saw	66	Smooth Synty	91	Coloful-Melody 4
17	SpiritVoice_5th	42	Synth Solo	67	Wide PWM	92	Colorful-Star
18	Tuba	43	Cantabile Saw	68	Saxy	93	Colorful-Shine
19	Solid Brass	44	Stonehenge	69	Oxygen	94	SP1 Cantabile Saw
20	Spuids+5	45	Crispy	70	Common Fanfare	95	SP2 Truth EWI 1
21	Pipe	46	Square Wave 10%	71	ClareInNet	96	Miyazaki 1
22	Tonette	47	Soft Pulse	72	YawnHummer+5	97	Miyazaki 2
23	OctaveSteps	48	Silky	73	Mass Ave.	98	Miyazaki 3
24	SteamPipe	49	Espresso	74	Dual Pulse	99	Miyazaki 4
25	Square Wave 50%	50	WoodNGLue	75	New Wood	100	Miyazaki 5